WIRING INSTRUCTIONS



8891004 &8891006 Strobes

- 1. Connect Red Strobe wire to 12-24VDC positive (+)
- 2. Connect White Ground wire to negative (-)
- 3. Only connect black constant on wire to positive (+) if used as a marker or running light, otherwise leave unconnected