

INSTALLATION INSTRUCTIONS

⚠ WARNING: DO NOT EXCEED PRODUCT RATING OR TOW VEHICLE LAMP LOAD RATING, WHICHEVER IS LOWER

APPLICATIONS

Make	Model
Cadillac	SRX

WIRING LOCATION GUIDE

SUVS, MINI & FULL-SIZED VANS (S)

Representative vehicle shown below

S6 - Behind center of rear bumper

CUSTOM WIRING CONNECTOR



NOTICE

All steps must be followed to ensure the wiring connector will function properly. Once installed, test for proper function by using a test light or connecting a properly wired trailer.

TOOLS NEEDED

Phillips screwdriver

Panel trim removal tool

⚠ WARNING

Exceeding the product rating can cause loss of warranty, overheating and potential fire. Do not exceed product rating or tow vehicle lamp load rating, whichever is lower.

Check vehicle owner's manual or contact the vehicle manufacturer for more information.

INSTALLATION / SAFETY INSTRUCTIONS

Step 1

Remove the two Phillips screws securing the bumper fascia (A).

Step 2

Behind the fascia panel, above the bumper beam, locate the vehicle taillight wiring connectors. The connectors will be similar to those on the custom wiring harness. Remove the white plastic cover from the connector taking care not to damage the locking tabs (B).

Step 3

Insert the custom wiring harness end into the vehicle connector. Make sure the connectors are fully inserted with locking tabs in place (C).

Step 4

When in use, route the 4-flat to the center of the vehicle and out of the trunk. When not in use, roll up and store in a convenient, out of the way location inside the trunk. Secure any loose wires with the provided cable ties.

Step 5

Reinstall all items removed during install. Install the provided 4-flat dust cover to help prevent corrosion.

