

CLASS 3 TRAILER HITCH

R3-0378

Honda Odyssey


TOOLS REQUIRED:

DRILLS: 1/2"

WRENCHES: Ratchet, Socket Extension,
Torque Wrench, 7/8", 19mm

HITCH RATING: 3,500 LBS WEIGHT CARRYING, 350 LBS TONGUE WEIGHT / 5,000 LBS WEIGHT DISTRIBUTING, 500 LBS TONGUE WEIGHT.
WARNING: CONSULT VEHICLE OWNERS MANUAL FOR TOWING RECOMMENDATIONS. DO NOT EXCEED VEHICLE'S RECOMMENDED TOWING CAPACITY. THIS PRODUCT IS DESIGNED FOR TRAILER TOWING ONLY AND SHOULD NOT BE USED FOR ANY OTHER PURPOSE.

NOTE: INSTALL PARTS LOOSELY UNTIL ALL ATTACHMENTS HAVE BEEN MADE TO VEHICLE




1. Lower the vehicle exhaust.
2. Raise the hitch into position and loosely attach (2) 12mm hex bolts into existing weld nuts in each side frame rail, using a 1/2" conical washer under the head of each bolt.
3. Use the hitch as a template to drill the 1/2" forward most hole on the passenger side frame rail, and enlarge the forward most mounting hole in the driver's side frame rail with 1/2" drill.
4. Insert a 1/2-13 x 1-3/4" carriage bolt and block plate into each frame rail through the access hole just forward of the hitch side plates and down into the forward most attachment hole drilled in step 3 above. Secure each carriage bolt with a 1/2-13 heavy hex nut and 1/2" conical washer provided.
5. Tighten (4) M12 hex bolts to 68 LB-FT. Tighten (2) 1/2" hex nuts to 60 LB-FT
6. Re-install the vehicle exhaust.

Thank you for purchasing a Rigid Hitch

Hardware Package: (4) M12 x 1.25 x 35mm hex bolts (2) 1/4 x 1 x 2" sq. hole block plates
(6) 1/2" conical washers (2) 1/2-13 heavy hex nuts
(2) 1/2-13 x 1-3/4" carriage bolts (1) 1/2" fish wire

GIVE THIS INSTRUCTION SHEET TO VEHICLE OWNER



THIS PRODUCT COMPLIES WITH SAFETY SPECIFICATIONS AND REQUIREMENTS FOR SAE AND VESC REGULATION V-5 FOR CONNECTING DEVICES AND TOWING SYSTEMS. DO NOT MODIFY THIS PRODUCT. INSTALL ONLY ON SPECIFIED VEHICLES IN GOOD CONDITION.

RIGID[®]
HITCH INCORPORATED
3301 WEST BURNSVILLE PARKWAY
BURNSVILLE, MN 55337

REV.
7/17