

CLASS 1 TRAILER HITCH

RT-388

Toyota Corolla

TOOLS REQUIRED:


DRILLS: NONE

WRENCHES: 17mm, 19mm

2,000 LB GROSS TRAILER WEIGHT, 200 LB TONGUE WEIGHT. WARNING: CONSULT VEHICLE OWNERS MANUAL FOR TOWING RECOMMENDATIONS AND LIMITATIONS. THIS PRODUCT IS DESIGNED FOR TRAILER TOWING ONLY AND SHOULD NOT BE USED FOR ANY OTHER PURPOSE.

WARNING: USE ONLY RIGID HITCH APPROVED AND MANUFACTURED DRAW BAR INSERT OR WARRANTY WILL BE VOID

NOTE: INSTALL PARTS LOOSELY UNTIL ALL ATTACHMENTS HAVE BEEN MADE TO VEHICLE



Note: Some models are equipped with a plastic appearance panel that must be removed before installing the hitch. Remove the three plastic push pins that attach the fascia to the panel and gently pull the panel downward to remove. Return the panel and push pins to the vehicle owner.

1. Remove tow hooks from the frame rails on both sides of vehicle and return hooks and hardware to vehicle owner.
2. Raise hitch into place and secure with the (4) 12mm hex bolts and conical washers provided.
3. Tighten all bolts to the appropriate torque specifications shown below.

Thank you for purchasing a Rigid Hitch

TIGHTEN ALL FASTENERS TO THE TORQUE SPECIFICATIONS SHOWN BELOW

Hardware Package:

- (4) 12 x 1.25 x 35mm Hex Bolts
- (4) 7/16" Conical Washers
- (1) UB-6001 Draw Bar Kit

GIVE THIS INSTRUCTION SHEET TO VEHICLE OWNER

BOLT TIGHTENING TORQUE (LB-FT)			
BOLT SIZE	TORQUE	BOLT SIZE	TORQUE
3/8"	25 LB FT	8MM	20 LB FT
7/16"	50 LB FT	10MM	38 LB FT
1/2"	60 LB FT	12MM	68 LB FT
3/4"	120 LB FT		

THIS PRODUCT COMPLIES WITH SAFETY SPECIFICATIONS AND REQUIREMENTS FOR SAE AND VESC REGULATION V-5 FOR CONNECTING DEVICES AND TOWING SYSTEMS. DO NOT MODIFY THIS PRODUCT. INSTALL ONLY ON SPECIFIED VEHICLES IN GOOD CONDITION.

RIGID[®]
HITCH INCORPORATED
 3301 WEST BURNSVILLE PARKWAY
 BURNSVILLE, MN 55337
www.rigidhitch.com